

**1.2 Overview of the equipment**

**1.2.1 Main components**

- Control panel: control of various functions (power, speed, direction, etc.)
- Motor: provides the driving force for the equipment.
- Roller: supports the equipment and allows it to move smoothly.
- Wheels: provide the main support and allow the equipment to move.
- Drive shaft: transmits the power from the motor to the rollers.
- Frame: provides structural support for the equipment.
- Wheels: provide the main support and allow the equipment to move.
- Drive shaft: transmits the power from the motor to the rollers.
- Control panel: control of various functions (power, speed, direction, etc.)

**1.2.2 Technical data**

Parameter	Value
Power	100 W
Speed	0.5 m/s
Direction	Forward/Reverse
Weight	1.5 kg
Dimensions	100 x 100 x 100 mm

**1.3 Accessories**

The following accessories are available for the equipment:

- Roller: for smooth movement on uneven surfaces.
- Wheels: for improved traction and stability.
- Drive shaft: for power transmission.
- Control panel: for easy operation.

**1.4 Safety, storage, and labels**

**1.4.1 Safety**

- Read the manual carefully before using the equipment.
- Do not touch the moving parts of the equipment.
- Do not use the equipment if you are tired or under the influence of alcohol or drugs.

**1.4.2 Storage**

- Store the equipment in a dry, well-ventilated area.
- Do not store the equipment outdoors.

**1.4.3 Labels**

- Labels provide important information about the equipment.
- Do not remove or damage the labels.

**1.5 Installation**

**1.5.1 Place of installation**

The equipment should be installed on a flat, hard surface. Avoid soft or uneven surfaces.

**1.5.2 Mounting**

Follow the steps below to mount the equipment:

- Remove the top cover of the equipment.
- Insert the mounting brackets into the designated slots.
- Tighten the screws to secure the brackets.

**1.6 Maintenance**

**1.6.1 Routine maintenance**

- Check the oil level in the motor regularly.
- Clean the rollers and wheels to remove dirt and debris.
- Inspect the drive shaft for wear and tear.

**1.6.2 Troubleshooting**

If the equipment does not start, check the following:

- Is the power switch turned on?
- Is the battery fully charged?
- Are the rollers and wheels free to rotate?

**1.7 Electrical connection**

**1.7.1 Connecting to a power source**

Connect the power cable to the power source. Ensure the connection is secure.

**1.7.2 Electrical safety**

Do not touch the electrical components of the equipment. Use caution when working with electricity.

**1.8 Maintenance**

**1.8.1 Routine maintenance**

- Check the oil level in the motor regularly.
- Clean the rollers and wheels to remove dirt and debris.
- Inspect the drive shaft for wear and tear.

**1.8.2 Troubleshooting**

If the equipment does not start, check the following:

- Is the power switch turned on?
- Is the battery fully charged?
- Are the rollers and wheels free to rotate?

**1.9 Special maintenance**

**1.9.1 Adjusting the play on the cable support**

Adjust the play on the cable support to ensure smooth operation.

**1.9.2 Replacing the rollers (200 and 300 versions)**

Replace the rollers if they are worn or damaged.

**1.10 Maintenance**

**1.10.1 Replacing the rollers (200 and 300 versions)**

Replace the rollers if they are worn or damaged.

**1.10.2 Troubleshooting**

If the equipment does not start, check the following:

- Is the power switch turned on?
- Is the battery fully charged?
- Are the rollers and wheels free to rotate?

**1.11 Troubleshooting**

**1.11.1 Troubleshooting**

If the equipment does not start, check the following:

- Is the power switch turned on?
- Is the battery fully charged?
- Are the rollers and wheels free to rotate?